

# Seesaw Assembly Instructions

1.) Pre assemble the height adjustment strips. Note that they are offset by one hole. When in this position the seesaw is at full height.



2.) Assemble the base. Note the cylinder position in the photo. The supplied screws should only fit together one way.



3.) When attaching the plank note that the "Clip and Go" logo will be the high end of the seesaw. Make sure it is attached in the proper orientation. If it's backwards the cylinder mechanism will not function.

Logo on "High side" of the plank



Cylinders on "down side" of the plank